

Preprocess Quality

100 Amerindian Genome Project

Cristóbal Fresno Joshua Haase

2017-05-08

Experiment

- 95 samples
 - paired end reads
 - length 150bp
 - experimental protocol?
 - sequencer?
- fastq
 - raw data
 - bgi
 - remove adapters
 - drop reads with 10% N
 - drop reads with $Q_{average} < 18$
 - inmegen
 - remove adapters
 - remove bases with $Q < 28$ from beginning
 - trim using sliding window of size 5 where $Q_{average} < 28$
 - drop reads where $length < 70$




Figure 1: Quality per base summary.

Not the best quality. BGI preprocess too permissive.




Figure 2: Quality per base detailed.

Experimental bias shown. Potentially from sequencer and/or flowcell.




Figure 3: Experimental design.

Not random at all!! Subjects confused with flowcell and sequencer.




Figure 4: Read density per quality.

Almost no difference between RAW and BGI. Clear quality improvement with our preprocessing.




Figure 5: Reads per subject.

~ 85% of reads kept.

Next steps

- Read alignment for HG38.
 - Pilot test with SNAP → GATK.
 - Alignment with BWA MEM.
- Alignment Quality Control using qualimap.
- Variant calling.
 - GATK variant annotation.
 - Phasing using 1000 genome reference.
 - Comparison with microarrays.
- Structural variant search.
- Positive selection.